



BODYFENCE

P A I N T P R O T E C T I O N F I L M

! INSTALLATION TIPS !

- **RECOMMENDED SLIP SOLUTION = 1ml of Blue Dawn Dish Soap in 1L Spray Bottle**
- **TACK SOLUTION= Filtered or Distilled Water (1:10 ratio of 70% Isopropyl Alcohol OPTIONAL)**
- **Pure shampoo can be used to remove dust or debris in hard to reach areas after PPF is installed**

EDGES NOT STICKING?

#1 - PPF is contaminated

#2 - There is too much or incorrect tension in that area

#3 - PPF is still saturated with the slip solution (shampoo)

***SOLUTION= rinse strong continuous flow of preferred tack solution while scrubbing edge with fingers until soap is removed.**

